



EVKT-USBSPI-00

USB to SPI

Communication Interface Device

DESCRIPTION

The EVKT-USBSPI-00 is a USB to SPI communication interface device. It is designed to work with MPS's SPI products and SPI GUI tools. The EVKT-USBSPI-00 kit includes one USB to SPI communication device interface,

one USB cable, one 10-pin ribbon cable, one 5-pin ribbon cable, one datasheet, and driver files. Together with MPS's SPI GUI tool, it provides a quick and easy way to evaluate the performance of MPS digital products.

EVKT-USBSPI-00



EVKT-USBSPI-00 CONNECTION



RIBBON CABLE DESCRIPTION

The EVKT-USBSPi-00 supports two kinds of ribbon cable connections between the communication interface device and the evaluation board: a 5-pin ribbon cable and a 10-pin ribbon cable. Figure 1 shows the bottom view of the 10-pin ribbon cable, and Table 1 shows the pin descriptions.




Figure 1: 10-Pin Ribbon Cable Bottom View

Table 1: 10-Pin Ribbon Cable Pins

Pin #	Description	Pin #	Description
1	SCL	2	GND
3	GND	4	SDI
5	SDA	6	SDO
7	GND	8	SCK
9	NC	10	NCS

QUICK START GUIDE

1. Connect the EVKT-USBSPi-00 to the evaluation board with the 5-pin ribbon cable or the 10-pin ribbon cable. ⁽¹⁾
2. Connect the EVKT-USBSPi-00 to the computer with the USB cable. ⁽¹⁾
3. Turn on the power supply for the evaluation board.
4. Start the SPI GUI software; it should check the connection automatically.

Note:

- 1) The sequence of steps 1 and 2 must be followed. Otherwise, the communication pins may be damaged during a hot-plug event.



REVISION HISTORY

Revision #	Revision Date	Description	Pages Updated
1.0	6/19/2023	Initial Release	-

Notice: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third-party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.